



GALAHAD

MOP

USER DOCUMENTATION

GALAHAD Optimization Library version 2.6

1 SUMMARY

GALAHAD_MOP is a suite of Fortran 90 procedures for **performing operations on/with a matrix \mathbf{A}** of derived data type `SMT_type` (Section 2.2), which allows for multiple storage types (Section 2.1). In particular, this package contains the following subroutines for a given m by n matrix \mathbf{A} :

- subroutine `mop_Ax` computes matrix-vector products of the form

$$\mathbf{r} \leftarrow \alpha \mathbf{A} \mathbf{x} + \beta \mathbf{r} \quad \text{and} \quad \mathbf{r} \leftarrow \alpha \mathbf{A}^T \mathbf{x} + \beta \mathbf{r}$$

for given scalars α and β , and vectors $\mathbf{x} \in \mathbb{R}^n$ and $\mathbf{r} \in \mathbb{R}^m$;

- subroutine `mop_getval` obtains the (i, j) -element of the matrix \mathbf{A} for given integers i and j ;
- subroutine `mop_scaleA` scales the rows of \mathbf{A} by a given vector $\mathbf{u} \in \mathbb{R}^m$ and the columns by a vector $\mathbf{v} \in \mathbb{R}^n$.

ATTRIBUTES — Versions: `GALAHAD_MOP_single`, `GALAHAD_MOP_double`, **Uses:** `GALAHAD_SMT_double`. **Date:** November 2009. **Origin:** N. I. M. Gould, Rutherford Appleton Laboratory, and D. P. Robinson, University of Oxford, UK. **Language:** Fortran 90.

2 HOW TO USE THE PACKAGE

Access to the package requires a `USE` statement such as

Single precision version

```
USE GALAHAD_MOP_single
```

Double precision version

```
USE GALAHAD_MOP_double
```

If it is required to use both modules at the same time, the derived type `SMT_type` (Section 2.2) and the subroutines `MOP_Ax`, `MOP_getval`, and `MOP_scaleA` (Sections 2.3, 2.4, 2.5) must be renamed on one of the `USE` statements.

2.1 Matrix storage formats

The matrix \mathbf{A} may be stored in a variety of input formats.

2.1.1 Dense storage format

The matrix \mathbf{A} is stored as a compact dense matrix by rows, that is, the values of the entries of each row in turn are stored in order within an appropriate real one-dimensional array. Component $n * (i - 1) + j$ of the storage array `A%val` will hold the value a_{ij} for $i = 1, \dots, m$, $j = 1, \dots, n$. If \mathbf{A} is symmetric, only the lower triangular part (that is the part a_{ij} for $1 \leq j \leq i \leq n$) should be stored. In this case the lower triangle will be stored by rows, that is component $i * (i - 1) / 2 + j$ of the storage array `A%val` will hold the value a_{ij} (and, by symmetry, a_{ji}) for $1 \leq j \leq i \leq n$.

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>.
For any commercial application, a separate license must be signed.

2.1.2 Sparse co-ordinate storage format

Only the nonzero entries of the matrices are stored. For the l -th entry of \mathbf{A} , its row index i , column index j and value a_{ij} are stored in the l -th components of the integer arrays `A%row`, `A%col` and real array `A%val`. The order is unimportant, but the total number of entries `A%ne` is also required. If \mathbf{A} is symmetric, the same scheme is applicable, except that only the entries in the lower triangle should be stored.

2.1.3 Sparse row-wise storage format

Again only the nonzero entries are stored, but this time they are ordered so that those in row i appear directly before those in row $i + 1$. For the i -th row of \mathbf{A} , the i -th component of an integer array `A%ptr` holds the position of the first entry in this row, while `A%ptr(m + 1)` holds the total number of entries plus one. The column indices j and values a_{ij} of the entries in the i -th row are stored in components $l = \text{A\%ptr}(i), \dots, \text{A\%ptr}(i + 1) - 1$ of the integer array `A%col`, and real array `A%val`, respectively. If \mathbf{A} is symmetric, the same scheme is applicable, except that only the entries in the lower triangle should be stored.

For sparse matrices, this scheme almost always requires less storage than its predecessor.

2.1.4 Sparse column-wise storage format

Again only the nonzero entries are stored, but this time they are ordered so that those in column j appear directly before those in column $j + 1$. For the j -th column of \mathbf{A} , the j -th component of the integer array `A%ptr` holds the position of the first entry in this column, while `A%ptr(n + 1)` holds the total number of entries plus one. The row indices i and values a_{ij} of the entries in the j -th column are stored in components $l = \text{A\%ptr}(j), \dots, \text{A\%ptr}(j + 1) - 1$ of the integer array `A%row`, and real array `A%val`, respectively. If \mathbf{A} is symmetric, the same scheme is applicable, except that only the entries in the lower triangle should be stored.

2.1.5 Diagonal storage format

If \mathbf{A} is diagonal (i.e., $a_{ij} = 0$ for all $1 \leq i \neq j \leq n$) only the diagonal entries a_{ii} for $1 \leq i \leq n$ should be stored, and the first n components of the array `A%val` should be used for this purpose.

2.2 The derived data type for holding the matrix \mathbf{A}

The matrix \mathbf{A} is stored using the derived data type `SMT_type` whose components are:

`m` is a scalar component of type default `INTEGER`, that holds the number of rows in the matrix.

`n` is a scalar component of type default `INTEGER`, that holds the number of columns in the matrix.

`ne` is a scalar variable of type default `INTEGER`, that holds the number of matrix entries.

`type` is a rank-one allocatable array of type default `CHARACTER`, that is used to indicate the matrix storage scheme used. If the dense storage scheme (see Section 2.1.1) is used, the first five components of `H%type` must contain the string `DENSE`. For the sparse co-ordinate scheme (see Section 2.1.2), the first ten components of `H%type` must contain the string `COORDINATE`, for the sparse row-wise storage scheme (see Section 2.1.3), the first fourteen components of `H%type` must contain the string `SPARSE_BY_ROWS`, for the sparse column-wise storage scheme (see Section 2.1.4), the first seventeen components of `H%type` must contain the string `SPARSE_BY_COLUMNS`, and for the diagonal storage scheme (see Section 2.1.5), the first eight components of `H%type` must contain the string `DIAGONAL`.

For convenience, the procedure `SMT_put` may be used to allocate sufficient space and insert the required keyword into `H%type`. For example, if we wish to store \mathbf{A} using the co-ordinate scheme, we may simply

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>.
For any commercial application, a separate license must be signed.

```
CALL SMT_put( A%type, 'COORDINATE' )
```

See the documentation for the GALAHAD package SMT for further details on the use of SMT_put.

- `val` is a rank-one allocatable array of type default REAL (double precision in GALAHAD_MOP_double) and dimension at least `ne`, that holds the values of the entries. Each pair of off-diagonal entries $a_{ij} = a_{ji}$ of a *symmetric* matrix **A** is represented as a single entry (see §2.1.1–2.1.5).
- `row` is a rank-one allocatable array of type default INTEGER, and dimension at least `ne`, that may hold the row indices of the entries (see § 2.1.2 and 2.1.4).
- `col` is a rank-one allocatable array of type default INTEGER, and dimension at least `ne`, that may hold the column indices of the entries (see §2.1.2–2.1.3).
- `ptr` is a rank-one allocatable array of type default INTEGER. If sparse row-wise storage is used, then `ptr` should be of dimension at least `m + 1` and should contain pointers to the first entry in each row (see §2.1.3). If sparse column-wise storage is used, then `ptr` should be of dimension at least `n + 1` and should contain pointers to the first entry in each column (see §2.1.4).

2.3 The subroutine to form matrix-vector products

The subroutine MOP_Ax may be called to compute matrix vector products with **A** of the form

$$\mathbf{r} \leftarrow \alpha \mathbf{A} \mathbf{x} + \beta \mathbf{r} \quad (2.1)$$

or

$$\mathbf{r} \leftarrow \alpha \mathbf{A}^T \mathbf{x} + \beta \mathbf{r} \quad (2.2)$$

by using

```
CALL MOP_Ax( alpha, A, X, beta, R, [out, error, print_level, symmetric, transpose] )
```

where square brackets indicate OPTIONAL arguments.

`alpha` is a scalar INTENT(IN) argument of type REAL (double precision in GALAHAD_MOP_double) that must hold the value of α .

`A` is a scalar INTENT(IN) argument of type SMT_type (see Section 2.2) that must hold the matrix **A**.

`X` is a rank-one INTENT(IN) array of type REAL (double precision in GALAHAD_MOP_double) that must contain the components of the vector **x**.

`beta` is a scalar INTENT(IN) argument of type REAL (double precision in GALAHAD_MOP_double) that must hold the value of β .

`R` is a rank-one INTENT(INOUT) array of type REAL (double precision in GALAHAD_MOP_double) that must contain the components of the vector **r**. `R` need not be set on entry if `beta` is zero.

`out` is an OPTIONAL scalar INTENT(IN) argument of type default INTEGER, that holds the stream number for informational messages. If this argument is not provided, then the default value `out = 6` is used.

`error` is an OPTIONAL scalar INTENT(IN) argument of type default INTEGER, that holds the stream number for error messages. If this argument is not provided, then the default value `error = 6` is used.

`print_level` is an OPTIONAL scalar INTENT(IN) argument of type default INTEGER, that is used to control the amount of informational output which is required. No informational output will occur if `print_level ≤ 0`. If `print_level = 1`, minimal output will be produced and if `print_level ≥ 2` then output will be increased to provide full details. The default is `print_level = 0`.

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>.
For any commercial application, a separate license must be signed.

`symmetric` is an OPTIONAL scalar INTENT(IN) argument of type default LOGICAL that should be set `.TRUE.` if the matrix **A** is symmetric, and set `.FALSE.` otherwise. If this argument is not provided, then the default value of `.FALSE.` is used.

`transpose` is an OPTIONAL scalar INTENT(IN) argument of type default LOGICAL that should be set `.FALSE.` if the user wishes to compute (2.1), and set `.TRUE.` if the user wishes to compute (2.2). If `transpose` is not provided, then the default value of `.FALSE.` is used.

2.3.1 Warning and error messages

All warning and error messages will be printed on unit `error` as discussed in the previous section.

2.3.2 Information printed

If `print_level` is positive, information about the calculation will be printed on unit `out` as discussed previously. In particular, if `print_level = 1`, then the values `symmetric`, `transpose`, `A%m`, `A%n`, `A%type`, `A%id`, `alpha`, and `beta` are printed. If `print_level = 2`, then additionally `A%ptr`, `A%val`, `A%row`, and `A%col` are printed. If `print_level ≥ 3`, then additionally the input **X** and **R** as well as the result **R** will be printed.

2.4 The subroutine to get matrix values

The subroutine `MOP_getval` may be used to get the (i, j) -th element of the matrix **A** by using

```
CALL MOP_getval( A, row, col, val, [symmetric, out, error, print_level] )
```

where square brackets indicate OPTIONAL arguments.

A is a scalar INTENT(IN) argument of type `SMT_type` (see Section 2.2) that must contain the matrix **A**.

`row` is a scalar INTENT(IN) argument of type `INTEGER` that specifies the row index i of the requested element of the matrix **A**.

`col` is a scalar INTENT(IN) argument of type `INTEGER` that specifies the column index j of the requested element of the matrix **A**.

`val` is a scalar INTENT(OUT) argument of type `REAL` (double precision in `GALAHAD_MOP_double`) that holds the value of the (i, j) -th element of the matrix **A** on return.

`symmetric` is an OPTIONAL scalar INTENT(IN) argument of type default LOGICAL that should be set `.TRUE.` if the matrix **A** is symmetric, and set `.FALSE.` otherwise. If `symmetric` is not provided, then the default value of `.FALSE.` is used.

`out` is an OPTIONAL scalar INTENT(IN) argument of type default `INTEGER`, that holds the stream number for informational messages. If this argument is not provided, then the default value `out = 6` is used.

`error` is an OPTIONAL scalar INTENT(IN) argument of type default `INTEGER`, that holds the stream number for error messages. If this argument is not provided, then the default value `error = 6` is used.

`print_level` is an OPTIONAL scalar INTENT(IN) argument of type default `INTEGER`, that is used to control the amount of informational output which is required. No informational output will occur if `print_level ≤ 0`. If `print_level = 1`, minimal output will be produced and if `print_level ≥ 2` then output will be increased to provide full details. The default is `print_level = 0`.

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>. For any commercial application, a separate license must be signed.

2.4.1 Warning and error messages

All warning and error messages will be printed on unit `error` as discussed in the previous section.

2.4.2 Information printed

If `print_level` is positive, information about the subroutine data will be printed on unit `out` as discussed previously. In particular, if `print_level = 1`, then the values `A%m`, `A%n`, `A%type`, `A%id`, `row`, `col`, and the resulting value `val` are printed. If `print_level ≥ 2`, then additionally `A%ptr`, `A%val`, `A%row`, and `A%col` are printed.

2.5 The subroutine to scale the matrix

The subroutine `MOP_scaleA` may be called to scale the rows of the m by n matrix \mathbf{A} by the vector $\mathbf{u} \in \mathbb{R}^m$ and the columns by the vector $\mathbf{v} \in \mathbb{R}^n$. In other words, it forms the scaled matrix whose (i, j) -th element is $u_i a_{i,j} v_j$. This scaled matrix is stored in \mathbf{A} on return. If the OPTIONAL argument `symmetric` is set `.TRUE.`, then the rows and columns of \mathbf{A} are scaled by the vector \mathbf{u} . The calling sequence is given by

```
CALL MOP_scaleA( A, [u, v, out, error, print_level, symmetric] )
```

where square brackets indicate OPTIONAL arguments.

`A` is a scalar `INTENT(INOUT)` argument of type `SMT_type` (see Section 2.2) that must contain the matrix \mathbf{A} .

`u` is an OPTIONAL rank-one `INTENT(IN)` argument of type `REAL` (double precision in `GALAHAD_MOP_double`) of length `A%m` whose i -th component is used to scale the i -th row of the matrix \mathbf{A} .

`v` is an OPTIONAL rank-one `INTENT(IN)` argument of type `REAL` (double precision in `GALAHAD_MOP_double`) of length `A%n` whose i -th component is used to scale the i -th column of the matrix \mathbf{A} .

`out` is an OPTIONAL scalar `INTENT(IN)` argument of type default `INTEGER`, that holds the stream number for informational messages. If this argument is not provided, then the default value `out = 6` is used.

`error` is an OPTIONAL scalar `INTENT(IN)` argument of type default `INTEGER`, that holds the stream number for error messages. If this argument is not provided, then the default value `error = 6` is used.

`print_level` is an OPTIONAL scalar `INTENT(IN)` argument of type default `INTEGER`, that is used to control the amount of informational output which is required. No informational output will occur if `print_level ≤ 0`. If `print_level = 1`, minimal output will be produced and if `print_level ≥ 2` then output will be increased to provide full details. The default is `print_level = 0`.

`symmetric` is an OPTIONAL scalar `INTENT(IN)` argument of type default `LOGICAL` that should be set `.TRUE.` if the matrix \mathbf{A} is symmetric, and set `.FALSE.` otherwise. If `symmetric` is not provided, then the default value of `.FALSE.` is used.

2.5.1 Warning and error messages

All warning and error messages will be printed on unit `error` as discussed in the previous section.

2.5.2 Information printed

If `print_level` is positive, information about the arguments will be printed on unit `out` as discussed previously. In particular, if `print_level ≥ 1`, then the values `A%m`, `A%n`, `A%type`, `A%id`, `A%ptr`, `A%val`, `A%row`, `A%col`, `u` and `v` will be printed.

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>.
For any commercial application, a separate license must be signed.

3 GENERAL INFORMATION

Use of common: None.

Workspace: Provided automatically by the module.

Other routines called directly: None.

Other modules used directly: The GALAHAD package GALAHAD_SMT is used by the subroutines MOP_Ax, MOP_getval, and MOP_scaleA.

Input/output: Output is provided under the control of the OPTIONAL input arguments `print_level`, `out`, and `error`. The argument `print_level` controls the amount of information printed to the device with unit number `out`; all error messages will be printed to the device with unit number `error`. If the user does not supply any of these optional arguments, then the default values `print_level = 0`, `out = 6`, and `error = 6` are used.

Restrictions: $A_{nn} > 0$, $A_{mm} > 0$, and $A\%type \in \{ 'DENSE', 'COORDINATE', 'SPARSE_BY_ROWS', 'SPARSE_BY_COLUMNS', 'DIAGONAL' \}$.

Portability: ISO Fortran 90.

4 EXAMPLE OF USE

Suppose we wish to perform the following operations. We first compute

$$\mathbf{r} \leftarrow \alpha \mathbf{A}\mathbf{x} + \beta \mathbf{r}$$

where

$$\mathbf{A} = \begin{pmatrix} 1 & 2 & 3 \\ 4 & 5 & 6 \end{pmatrix}, \quad \mathbf{x} = \begin{pmatrix} 1 \\ 1 \\ 1 \end{pmatrix}, \quad \mathbf{r} = \begin{pmatrix} 3 \\ 3 \end{pmatrix}, \quad \alpha = 3, \quad \text{and} \quad \beta = 2.$$

Next we scale the rows of \mathbf{A} by the vector \mathbf{u} and columns of \mathbf{A} by the vector \mathbf{v} , where

$$\mathbf{u} = \begin{pmatrix} 2 \\ -1 \end{pmatrix} \quad \text{and} \quad \mathbf{v} = \begin{pmatrix} 3 \\ 1 \\ 2 \end{pmatrix}.$$

In other words, we over-write the matrix \mathbf{A} with the scaled matrix whose (i, j) th element is $u_i a_{i,j} v_j$. Finally, we retrieve the $(1, 2)$ element of the scaled matrix.

We may use the following code

```
! THIS VERSION: GALAHAD 2.4 - 4/02/2008 AT 09:00 GMT.
PROGRAM GALAHAD_mop_example
  USE GALAHAD_SMT_double ! double precision version
  USE GALAHAD_MOP_double ! double precision version
  IMPLICIT NONE
  integer, parameter :: wp = KIND( 1.0D+0 ) ! Define the working precision
  real (kind = wp), parameter :: one = 1.0_wp, two = 2.0_wp, three = 3.0_wp
  real (kind = wp), dimension(:), allocatable :: X, u, v, R
  real (kind = wp) :: val, alpha, beta
  integer :: m, n, row, col, out, error, print_level, stat
  logical :: symmetric, transpose
  type( SMT_type ) :: A
  ! Begin problem data.
  A%m = 2 ; A%n = 3 ; A%ne = 6
```

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>.
For any commercial application, a separate license must be signed.

```

allocate( A%row( A%ne ), A%col( A%ne ), A%val( A%ne ), X( A%n ), u( A%m ), v( A%n ), R( A%m ) )
A%row = (/ 1, 1, 1, 2, 2, 2 /) ; A%col = (/ 1, 2, 3, 1, 2, 3 /) ; A%val = (/ 1, 2, 3, 4, 5, 6 /)
call SMT_put( A%id, 'Toy 2x3 matrix', stat )
call SMT_put( A%type, 'COORDINATE', stat )
X = (/ one, one, one /) ; R = (/ three, three /)
u = (/ two, -one /) ; v = (/ three, one, two /)
! Compute : R <- 3*A X + 2*R
alpha = three ; print_level = 3
beta = two ; symmetric = .false.
out = 6 ; transpose = .false.
error = 6
write(*,*) 'Compute R <- alpha*A*X + beta*R .....'
call mop_Ax( alpha, A, X, beta, R, out, error, print_level, symmetric, transpose )
! Scale rows of A by u and columns by v.
write(*,*) 'Scale rows of A by u and columns by v .....'
call mop_scaleA( A, u, v, out, error, print_level, symmetric )
! Get the (1,2) element of scaled matrix.
row = 1 ; col = 2
write(*,*) 'Obtain the (1,2) element of the scaled matrix A .....'
call mop_getval( A, row, col, val, symmetric, out, error, print_level )
write(*,*) 'The value of the (1,2) element of the scaled matrix is', val
END PROGRAM GALAHAD_mop_example

```

This produces the following output:

```

Compute R <- alpha*A*X + beta*R .....

*****
*                               *
*          BEGIN: mop_Ax        *
*          GALAHAD sparse matrix operation subroutine          *
*                               *
*****

A%type = COORDINATE
A%id   = Toy 2x3 matrix

transpose = F      m =      2      alpha = 3.0000000000E+00
symmetric = F      n =      3      beta  = 2.0000000000E+00

      A%row      A%col      A%val
      ----      ----      -
      1          1          1.0000000000E+00
      1          2          2.0000000000E+00
      1          3          3.0000000000E+00
      2          1          4.0000000000E+00
      2          2          5.0000000000E+00
      2          3          6.0000000000E+00

      X          R(in)
      ----      -
1.0000000000E+00  3.0000000000E+00
1.0000000000E+00  3.0000000000E+00
1.0000000000E+00

      R (out)
      ----
2.4000000000E+01

```

All use is subject to licence. See <http://galahad.rl.ac.uk/galahad-www/cou.html>.
For any commercial application, a separate license must be signed.

```
*****
*                                     *
*                               END: mop_Ax                                *
*                                     *
*****
```

```
*****
*                               BEGIN: mop_scaleA                               *
*                               GALAHAD sparse matrix operation subroutine        *
*****
```

```
*****
*                               END: mop_scaleA                               *
*****
```

GALAHAD


```
*****
*                               BEGIN: mop_getval                               *
*   GALAHAD gets a single element of a sparse matrix                         *
*****
```

```
A%type = COORDINATE
A%id   = Toy 2x3 matrix
```

```
m =    2    row =    1    symmetric = F
n =    3    col =    2
```

A%row	A%col	A%val
-----	-----	-----
1	1	6.0000000000E+00
1	2	4.0000000000E+00
1	3	1.2000000000E+01
2	1	-1.2000000000E+01
2	2	-5.0000000000E+00
2	3	-1.2000000000E+01

```
ON EXIT: value = 4.000000000E+00
```

```
*****
*                               END: mop_getval                               *
*****
```

The value of the (1,2) element of the scaled matrix is 4.